

8 Saskatchewan Avenue  
Devon AB. T9G 1E7  
P. 780 487 8878  
F. 780 987 2838  
www.tteheat.com



### GreenTech Heater Setup:

**Note: Basic prep needs to be followed**

- 1) Set heater in room to be treated – make sure nothing is blocking the inlet or outlet of the heater. Do not point heater directly towards anything that can be affected by high heat.
  - 2) Connect the GREEN cord to A and D and plug into an outlet in the room being treated. Plug the other two cords into the heater and then run those cords out of the room to other circuits. Example: Hall plug in, Bathroom, Kitchen plug.
  - 3) If plugged in correctly, all yellow lights above the plugs connected to the heater should be on. Follow directions on the heater to power up the heater.
  - 4) Point the heater alongside of the bed pointing toward the head board.
  - 5) **The heater is set to 160F and will heat until this temperature is reached. It will turn off the heater elements and drop to approx. 142F then turn on. If you enter the room and temperature has dropped below 140F make sure the light in the upper right corner and lower left corner are on. If not press the ON switch on the thermostat.**
  - 6) After 3 or 4 hours, change the direction of the heater to the other side of the bed pointing towards the foot area. You can also point heater toward closet for a while. Or any other area you feel need heating.
  - 7) Hint is to remove bottom dresser drawers and then open other drawers slightly and blow the heat through the bottom opening. Bed bugs like dressers. Also flip mattress during the treatment to insure heat getting all the way through it.
  - 8) Check temps every hour and redirect the heater to cooler areas of the room or take heat away from hotter areas.
  - 9) Do not leave temp gun in the room being treated.
  - 10) If you check on the heater and four heater lights are out, check the circuit panel in the home as more than likely you have two heater elements on one circuit in the house. You will need to move one of the extension cords to another outlet in the house. This sometimes is trial and error as all houses are wired differently.
  - 11) NOTE: this equipment should not be used to heat bathrooms due to plumbing concerns.
  - 12) If you have any questions, please call 780-986-4484
-

8 Saskatchewan Avenue  
Devon AB. T9G 1E7

P. 780 487 8878  
F. 780 987 2838  
www.tteheat.com



## **Basic Prep required for successful heat treatment**

- 1) Remove all heat sensitive items like Candles, Aerosol cans, Live Plants, etc.
  - 2) Unplug all Electronic Equipment. Cover TVs with blanket or comforter.
  - 3) Spread out Clutter. If there is anything under the beds, pull it out and spread it out.
  - 4) Make sure all dresser drawers are empty and the clothing removed has been treated in the dryer on high heat for at least 45 min.
  - 5) Throw out all cardboard as this is great hiding place for Bed Bugs. Also hard to heat through.
  - 6) Clothing that is hanging is OK. Just leave it. If there is room hang other clothing from dresser drawers.
  - 7) After the room gets hot (at least 2 hrs.) then take the mattress and lift it and prop it against the wall. This will separate boxspring and mattress.
  - 8) Move items around to allow good penetration of heat. Heat room for at least 8 to 10 hrs.
  - 9) After room has been treated, allow to cool down and then vacuum the room thoroughly.
-